

# New functionalities for LXM05

AC Servo drive

Extension to product manual

V1.00, 08.2008

019844113688, V1.00, 08.2008



[www.schneider-electric.com](http://www.schneider-electric.com)



## Important information

The new functionalities described in this manual are additions to the device functions described in the product manual. Always read the product manual carefully prior to commissioning.

The chapter "Safety" in the product manual contains additional important information.

**Not all product variants are available in all countries.**

Please consult the current catalog for information on the availability of product variants.

We reserve the right to make changes during the course of technical developments.

All details provided are technical data and not warranted quality.

In general, product names must be considered to be trademarks of the respective owners, even if not specifically identified as such.

# Table of Contents

- Important information . . . . . 2**
- Table of Contents . . . . . 3**
- 1 LXM05A . . . . . 5**
  - 1.1 "Quick Stop" with deceleration ramp . . . . . 5
  - 1.2 "Halt" with deceleration ramp . . . . . 6
  - 1.3 Saving the preferred method of reference movement . . . 7
  - 1.4 Threshold values and windows . . . . . 9
    - 1.4.1 Threshold values ("current threshold reached",  
"speed threshold reached") . . . . . 9
    - 1.4.2 Thresholds ("current threshold reached",  
"speed threshold reached") and windows  
("in position window", "in speed window"). . . . . 9
  - 1.5 Working range with multiturn encoder. . . . . 10
- 2 LXM05B . . . . . 13**
  - 2.1 "Quick Stop" with deceleration ramp . . . . . 13
  - 2.2 "Halt" with deceleration ramp . . . . . 14
  - 2.3 Saving the preferred method of reference movement . . 15
  - 2.4 External encoder . . . . . 17
  - 2.5 Working range with multiturn encoder. . . . . 22
- 3 LXM05C . . . . . 25**
  - 3.1 Threshold values ("current threshold reached",  
"speed threshold reached"). . . . . 25



# 1 LXM05A

Functionality	Page
1.1 "Quick Stop" with deceleration ramp"	5
1.2 "Halt" with deceleration ramp"	6
1.3 "Saving the preferred method of reference movement"	7
1.4 "Threshold values and windows"	9
1.5 "Working range with multiturn encoder"	10

These new functionalities are available from software version 1.501. The leading document is the product manual for the device.

*Source product manuals*

The current product manuals are available for download from the Internet.  
<http://www.schneider-electric.com>

## 1.1 "Quick Stop" with deceleration ramp

*So far* The "Quick Stop" function decelerates the motor very quickly when a Class 1 or Class 2 error or a software stop occur. Until now, the motor was always decelerated with a torque ramp.

*New* When the "Quick Stop" function is triggered, the motor can also be decelerated with a deceleration ramp in the Profile Position, Profile Velocity and Motion Sequence operating modes.

*Prerequisite*

- Software version from 1.501
- can only be performed in fieldbus control mode and only via fieldbus
- Available for operating modes with profile generator only (profile position, profile velocity and motion sequence). In all other operating modes, deceleration is only possible with a torque ramp.

*Function principle* The motor may be decelerated via a deceleration ramp or a torque ramp. Set the type of deceleration with the `LIM_QStopReact` parameter.

- ▶ Use the `LIM_QStopReact` parameter to define the required type of deceleration.
- ▶ Use the `RAMPquickstop` parameter to define a required deceleration ramp or the `LIM_I_maxQSTP` parameter to set a required maximum current for the torque ramp.

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
LIM_QStopReact	Type of deceleration for Quick Stop	-	INT16	CANopen 605A:0 <sub>h</sub>
-	<b>6 / Deceleration ramp:</b> Deceleration ramp	6	INT16	Modbus 1584
-	<b>7 / Torque ramp:</b> Torque ramp	7	R/W	
-	Setting of deceleration ramp with parameter RAMPquickstop. Setting of torque ramp with parameter LIM_I_maxQSTP.	7	per.	
	The deceleration ramp is only available for operating modes with profile generator. The torque ramp is always used in the operating modes without profile generator.		-	
RAMPquickstop	Deceleration ramp for Quick Stop	(1/min)/s	UINT32	CANopen 3006:12 <sub>h</sub>
-	Deceleration of the drive when a software stop is triggered or if an error of error class 1 has occurred.	200	UINT32	Modbus 1572
-		6000	R/W	
		3000000	per.	
			-	
LIM_I_maxQSTP	Current limitation for Quick Stop	A <sub>pk</sub>	UINT16	CANopen 3011:5 <sub>h</sub>
SET- - LiQS	Max. current during braking via torque ramp due to an error of error classes 1 or 2 and when a software stop is triggered.	-	UINT16	Modbus 4362
SEt - - L, 95		-	R/W	
	Maximum and default settings depend on the motor and the power amplifier (settings M_I_max and PA_I_max)		per.	
	In increments of 0.01A <sub>pk</sub>		-	

## 1.2 "Halt" with deceleration ramp

*So far* The "Halt" function temporarily interrupts the running operation and stops the motor. Until now, the motor was always stopped with a torque ramp.

*New* When the "Halt" function is triggered, the motor may also be decelerated with a deceleration ramp in the Profile Position, Profile Velocity and Motion Sequence operating modes.

- Prerequisite*
- Software version from 1.501
  - can only be performed in fieldbus control mode and only via fieldbus
  - Available for operating modes with profile generator only (profile position, profile velocity and motion sequence). In all other operating modes, deceleration is only possible with a torque ramp.

*Function principle* The motor may be decelerated via a deceleration ramp or a torque ramp. Set the type of deceleration with the LIM\_HaltReaction parameter.

- ▶ Use the LIM\_HaltReaction parameter to define the required type of deceleration.
- ▶ Use the RAMPdecel parameter to define a required deceleration ramp or the LIM\_I\_maxHalt parameter to set a required maximum current for the torque ramp.

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
LIM_HaltReaction	Type of deceleration for halt	-	INT16	CANopen 605D:0 <sub>h</sub>
-	<b>1 / Deceleration ramp:</b> Deceleration ramp	1	INT16	Modbus 1582
-	<b>3 / Torque ramp:</b> Torque ramp	3	R/W	
-	Setting of deceleration ramp with parameter RAMPdecel. Setting of torque ramp with parameter LIM_I_maxHalt.	3	per.	
	The deceleration ramp is only available for operating modes with profile generator. The torque ramp is always used in the operating modes without profile generator.		-	
RAMPdecel	Deceleration of profile generator	(1/min)/s	UINT32	CANopen 6084:0 <sub>h</sub>
-		750	UINT32	Modbus 1558
-		750	R/W	
-		3000000	per.	
			-	
LIM_I_maxHalt	Current limitation for Halt	A <sub>pk</sub>	UINT16	CANopen 3011:6 <sub>h</sub>
SET- - LihA	Max. current during braking after Halt or when an operating mode is terminated.	-	UINT16	Modbus 4364
SEt - - L, hR		-	R/W	
	Maximum and default settings depend on the motor and the power amplifier (settings M_I_max and PA_I_max)		per.	
	In increments of 0.01A <sub>pk</sub>		-	

### 1.3 Saving the preferred method of reference movement

*So far* Homing establishes an absolute dimension reference of the motor position to a defined axis position. There are various methods of homing which can be selected via the HMmethod parameter. The preferred method of reference movement could not yet be stored.

*New* The preferred method of reference movement can be specified in the SaveHomeMethod parameter.

- Prerequisite*
- Software version from 1.501
  - can only be performed in fieldbus control mode and only via fieldbus

*Function principle* The SaveHomeMethod parameter is used to save the preferred method of reference movement persistently in the EEPROM. When the preferred method was defined in this parameter, the method will be performed during homing even after the device has been switched off and on. The value to be entered corresponds to the value in the HMmethod parameter.

If the SaveHomeMethod parameter is not modified, the default reference movement is to the positive limit switch (LIMP).

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
SaveHomeMethod	Default homing method	- 1 18 35	INT16 INT16 R/W per. -	CANopen 301B:1C <sub>h</sub> Modbus 6968
HMmethod	Homing method	- 1 18 35	INT8 INT16 R/W - -	CANopen 6098:0 <sub>h</sub> Modbus 6936
-	1: LIMN with index pulse			
-	2: LIMP with index pulse			
-	7: REF+ with index pulse, inv., outside			
	8: REF+ with index pulse, inv., inside			
	9: REF+ with index pulse, not inv., inside			
	10: REF+ with index pulse, not inv., outside			
	11: REF- with index pulse, inv., outside			
	12: REF- with index pulse, inv., inside			
	13: REF- with index pulse, not inv., inside			
	14: REF- with index pulse, not inv., outside			
	17: LIMN			
	18: LIMP			
	23: REF+, inv., outside			
	24: REF+, inv., inside			
	25: REF+, not inv., inside			
	26: REF+, not inv., outside			
	27: REF-, inv., outside			
	28: REF-, inv., inside			
	29: REF-, not inv., inside			
	30: REF-, not inv., outside			
	33: Index pulse neg. direction			
	34: Index pulse pos. direction			
	35: Position setting			
	Abbreviations:			
	REF+: Search movement in pos. direction			
	REF-: Search movement in pos. direction			
	inv.: Invert direction in switch			
	not inv.: Direction not inverted in switch			
	outside: Index pulse / distance outside switch			
	inside: Index pulse / distance inside switch			

## 1.4 Threshold values and windows

- The "current threshold reached" and "speed threshold reached" thresholds can be assigned to configurable outputs in all operating modes
- Threshold values and windows ("current threshold reached", "speed threshold reached", "in position window", "in speed window") can be output in the DS402 status word, Bit11

### 1.4.1 Threshold values ("current threshold reached", "speed threshold reached")

*So far* The "current threshold reached" and "speed threshold reached" functions could only be assigned to configurable outputs in some operating modes.

*New* The "current threshold reached" and "speed threshold reached" functions can now be assigned to the configurable outputs in all operating modes

*Prerequisite* • Software version from 1.501

*Function principle* The "current threshold reached" and "speed threshold reached" functions are available in all operating modes and can be assigned to the configurable outputs. (See "Configurable inputs and outputs" in the product manual).

Function	Jog	Electronic gear	Speed control	Current control	Motion sequence	CANopen / Modbus
Speed threshold reached	•	•	•	•	•	•
Current threshold reached	•	•	•	•	•	•

### 1.4.2 Thresholds ("current threshold reached", "speed threshold reached") and windows ("in position window", "in speed window")

*So far* The status of the "current threshold reached", "speed threshold reached", "in position window" and "in speed window" was not mapped in any parameter.

*New* The previously unused Bit 11 in the `DCOMstatus` parameter can now indicate the status of the "current threshold reached", "speed threshold reached", "in position window" or "in speed window" functions. The value to be indicated can be set via the `SelectIntLim` parameter.

*Prerequisite* • Software version from 1.501

*Function principle* Bit 11 in the `DCOMstatus` parameter signals whether a defined current value or speed is exceeded or if a speed range or position deviation is kept. The value to be indicated can be defined in the `SelectIntLim` parameter.

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
SelectIntLim	Selection of internal limit for statusword (DS402)	- 0	UINT16 UINT16	CANopen 301B:1B <sub>h</sub> Modbus 6966
-	<b>0 / not used (reserved):</b> Bit 11 of statusword (DS402) not used (reserved)	0	R/W	
-	<b>1 / Current threshold reached:</b> Bit 11 of statusword (DS402): Current threshold reached	4	-	
	<b>2 / Speed threshold reached:</b> Bit 11 of statusword (DS402): Speed threshold reached			
	<b>3 / In Position Window:</b> Bit 11 of statusword (DS402): In Position Window			
	<b>4 / In Speed Window:</b> Bit 11 of statusword (DS402): In Speed Window			
DCOMstatus	Drivecom status word	-	UINT16	CANopen 6041:0 <sub>h</sub>
-	Refer to chapter Operation, State Machine for bit coding information.	0	UINT16	Modbus 6916
-	Bit0-3,5,6: Status bits	-	R/-	
	Bit4: Voltage enabled		-	
	Bit7: Warning			
	Bit8: HALT request active			
	Bit9: Remote			
	Bit10: Target reached			
	Bit11: Internal limit active			
	Bit12: Op. mode-specific			
	Bit13: x_err			
	Bit14: x_end			
	Bit15: ref_ok			

### 1.5 Working range with multiturn encoder

*So far* When a motor with multiturn encoder is moved counter-clockwise from the absolute position 0, the multiturn encoder encounters an underrun of its absolute position. In contrast, the internal actual position counts mathematically forward and delivers a negative position value. After switching off and on, the internal actual position no longer corresponds with the negative position value but the absolute position of the encoder (e.g. a position of -10 rotations before switching off becomes an absolute position of 4086 revolutions after switching on again).

*New* The `ShiftEncWorkRang` parameter is used to define whether the working range is 0...4096 rotations as it was until now or whether the working range is -2048...+2048 rotations.

*Prerequisite* • Software version from 1.501

*Function principle* `ShiftEncWorkRang = 0`: The working range is defined from 0 ... 4096 rotations. Function as described in the product manual.  
`ShiftEncWorkRang = 1`: The working range is defined from -2048 ... 2048 revolutions. With a typical application (positive and negative direction of rotation), the working range of the motor is in the constant range of the encoder.




Figure 1.1 Position values of multiturn encoder

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
ShiftEncWorkRang	Shifting the encoder working range	-	UINT16	CANopen 3005:20 <sub>h</sub>
-	<b>0 / not shifted:</b> Working range: 0 to maximum number of encoder revolutions	0	UINT16	Modbus 1344
-	<b>1 / shifted:</b> Working range: negative half of maximum number of encoder revolutions to positive half of maximum number of encoder revolutions	0 1	R/W per.	-
	Available in software version V1.501 and higher.			

0198441113688, V1.00, 08.2008



## 2 LXM05B

Functionality	Page
2.1 "Quick Stop" with deceleration ramp"	13
2.2 "Halt" with deceleration ramp"	14
2.3 "Saving the preferred method of reference movement"	15
2.4 "External encoder"	17
2.5 "Working range with multturn encoder"	22

These new functionalities are available from software version 1.501. The leading document is the product manual for the device.

*Source product manuals* The current product manuals are available for download from the Internet.  
<http://www.schneider-electric.com>

### 2.1 "Quick Stop" with deceleration ramp

*So far* The "Quick Stop" function decelerates the motor very quickly when a Class 1 or Class 2 error or a software stop occur. Until now, the motor was always decelerated with a torque ramp.

*New* When the "Quick Stop" function is triggered, the motor can also be decelerated with a deceleration ramp in the Profile Position, Profile Velocity and Motion Sequence operating modes.

*Prerequisite*

- Software version from 1.501
- can only be performed in fieldbus control mode and only via fieldbus
- Available for operating modes with profile generator only (profile position, profile velocity and motion sequence). In all other operating modes, deceleration is only possible with a torque ramp.

*Function principle* The motor may be decelerated via a deceleration ramp or a torque ramp. Set the type of deceleration with the `LIM_QStopReact` parameter.

- ▶ Use the `LIM_QStopReact` parameter to define the required type of deceleration.
- ▶ Use the `RAMPquickstop` parameter to define a required deceleration ramp or the `LIM_I_maxQSTP` parameter to set a required maximum current for the torque ramp.

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
LIM_QStopReact	Type of deceleration for Quick Stop	-	INT16	Modbus 1584
-	<b>6 / Deceleration ramp:</b> Deceleration ramp	6	INT16	Profibus 1584
-	<b>7 / Torque ramp:</b> Torque ramp	7	R/W	
-	Setting of deceleration ramp with parameter RAMPquickstop. Setting of torque ramp with parameter LIM_I_maxQSTP.	7	per.	
	The deceleration ramp is only available for operating modes with profile generator. The torque ramp is always used in the operating modes without profile generator.		-	
RAMPquickstop	Deceleration ramp for Quick Stop	(1/min)/s	UINT32	Modbus 1572
-	Deceleration of the drive when a software stop is triggered or if an error of error class 1 has occurred.	200	UINT32	Profibus 1572
-		6000	R/W	
		3000000	per.	
			-	
LIM_I_maxQSTP	Current limitation for Quick Stop	A <sub>pk</sub>	UINT16	Modbus 4362
SET- - LiQS	Max. current during braking via torque ramp due to an error of error classes 1 or 2 and when a software stop is triggered.	-	UINT16	Profibus 4362
SEt - - L, 95		-	R/W	
	Maximum and default settings depend on the motor and the power amplifier (settings M_I_max and PA_I_max)		per.	
	In increments of 0.01A <sub>pk</sub>		-	

## 2.2 "Halt" with deceleration ramp

*So far* The "Halt" function temporarily interrupts the running operation and stops the motor. Until now, the motor was always stopped with a torque ramp.

*New* When the "Halt" function is triggered, the motor may also be decelerated with a deceleration ramp in the Profile Position, Profile Velocity and Motion Sequence operating modes.

- Prerequisite*
- Software version from 1.501
  - can only be performed in fieldbus control mode and only via fieldbus
  - Available for operating modes with profile generator only (profile position, profile velocity and motion sequence). In all other operating modes, deceleration is only possible with a torque ramp.

*Function principle* The motor may be decelerated via a deceleration ramp or a torque ramp. Set the type of deceleration with the LIM\_HaltReaction parameter.

- ▶ Use the LIM\_HaltReaction parameter to define the required type of deceleration.
- ▶ Use the RAMPdecel parameter to define a required deceleration ramp or the LIM\_I\_maxHalt parameter to set a required maximum current for the torque ramp.

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
LIM_HaltReaction	Type of deceleration for halt	-	INT16	Modbus 1582
-	<b>1 / Deceleration ramp:</b> Deceleration ramp	1	INT16	Profibus 1582
-	<b>3 / Torque ramp:</b> Torque ramp	3	R/W	
-	Setting of deceleration ramp with parameter RAMPdecel. Setting of torque ramp with parameter LIM_I_maxHalt.	3	per.	
	The deceleration ramp is only available for operating modes with profile generator. The torque ramp is always used in the operating modes without profile generator.		-	
RAMPdecel	Deceleration of profile generator	(1/min)/s	UINT32	Modbus 1558
-		750	UINT32	Profibus 1558
-		750	R/W	
-		3000000	per.	
LIM_I_maxHalt	Current limitation for Halt	A <sub>pk</sub>	UINT16	Modbus 4364
SET- - LihA	Max. current during braking after Halt or when an operating mode is terminated.	-	UINT16	Profibus 4364
SEt - - L, hR	Maximum and default settings depend on the motor and the power amplifier (settings M_I_max and PA_I_max)	-	R/W	
	In increments of 0.01A <sub>pk</sub>		per.	

### 2.3 Saving the preferred method of reference movement

*So far* Homing establishes an absolute dimension reference of the motor position to a defined axis position. There are various methods of homing which can be selected via the `HMmethod` parameter. The preferred method of reference movement could not yet be stored.

*New* The preferred method of reference movement can be defined in the `SaveHomeMethod` parameter.

- Prerequisite*
- Software version from 1.501
  - can only be performed in fieldbus control mode and only via fieldbus

*Function principle* The `SaveHomeMethod` parameter is used to save the preferred method of reference movement persistently in the EEPROM. When the preferred method was defined in this parameter, the method will be performed during homing even after the device has been switched off and on. The value to be entered corresponds to the value in the `HMmethod` parameter.

If the `SaveHomeMethod` parameter is not modified, the default reference movement is to the positive limit switch (`LIMP`).

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
SaveHomeMethod	Default homing method	- 1	INT16 INT16	Modbus 6968 Profibus 6968
-		18	R/W	
-		35	per. -	
HMmethod	Reference movement type	- 0	UINT16 UINT16	Modbus 10242 Profibus 10242
-	<b>0 / deactivate:</b> Deactivated	-	R/W	
-	<b>1 / LIMN indexpuls:</b> LIMN with index pulse	35	-	
	<b>2 / LIMP indexpuls:</b> LIMP with index pulse		-	
	<b>7 / REFpos indexpuls:</b> REF+ with index pulse, inv., outside		-	
	<b>8 / REFneg indexpuls:</b> REF+ with index pulse, inv., inside			
	<b>9:</b> REF+ with index pulse, not inv., inside			
	<b>10:</b> REF+ with index pulse, not inv., outside			
	<b>11:</b> REF- with index pulse, inv., outside			
	<b>12:</b> REF- with index pulse, inv., inside			
	<b>13:</b> REF- with index pulse, not inv., inside			
	<b>14:</b> REF- with index pulse, not inv., outside			
	<b>17 / LIMN:</b> LIMN			
	<b>18 / LIMP:</b> LIMP			
	<b>23 / REFpos:</b> REF+, inv., outside			
	<b>24:</b> REF+, inv., inside			
	<b>25:</b> REF+, not inv., inside			
	<b>26:</b> REF+, not inv., outside			
	<b>27 / REFneg:</b> REF-, inv., outside			
	<b>28:</b> REF-, inv., inside			
	<b>29:</b> REF-, not inv., inside			
	<b>30:</b> REF-, not inv., outside			
	<b>33:</b> Index pulse neg. direction			
	<b>34:</b> Index pulse pos. Direction			
	Abbreviations: REF+: Search movement in pos. direction REF-: Search movement in pos. direction inv.: Invert direction in switch not inv.: Direction not inverted in switch outside: Index pulse / distance outside switch inside: Index pulse / distance inside switch			

## 2.4 External encoder

*Availability* The function is available from software version 1.501.

*Function principle* The "External Encoder" function can be used to transmit positioning values to the position controller using a digital incremental encoder (e.g. a linear glass scale), independently of the motor encoder. This external encoder can be used to carry out direct position measurement in the installation (actual position). The external encoder has no influence on the speed and current controllers. The motor encoder always has affects the speed of rotation and current controller.




Figure 2.1 Controller structure with external encoder

*Connection external encoder* The external encoder is connected to input CN5, see also chapter "Connecting sensor signals A,B" in the product manual. The following must be taken into consideration:

- The external encoder occupies the connection CN5. Neither "Electronic Gear" operating mode nor the ESIM function is possible.
- Only A/B signals are evaluated.
- The external A/B encoder must not exceed a maximum frequency of 1.6MHz or 400kHz for each A/B signal (quadruple evaluation).
- The external encoder must have a separate power supply.
- The IOposInterfac parameter must be set to "0 / A/Binput".

*Changing the motion dynamics* The motion dynamics of the system change, especially with a soft coupling. The position controller receives the position information with a time delay caused by the chain of mechanical couplings. Slip between the motor shaft, mechanical components and the external encoder must be avoided

*Influence on the positioning accuracy*

The positioning accuracy can also change, depending upon the resolution of the external encoder. If the encoder resolution is lower, the running of the motor will be rougher and the noise from the motor will increase.

For example, a Hiperface motor encoder has a resolution of 1024 increments per revolution and acts on a 12bit analog-digital converter. Internal calculations are then based on 8388608 increments per revolution. With an external digital encoder having a resolution of 1024 increments per revolution, internal calculations are based on 4096 increments. The accuracy of the external encoder is thus less by a factor of 2048. A mechanical gearbox between the motor shaft and the external encoder impairs this result again, depending upon the gear ratio.

*An absolute position is not possible*

The signals of the external encoder are only counted incrementally. The counter starts at 0 every time you switch on. There is no absolute position.

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
IOposInterfac	Signal selection position interface	-	UINT16	Modbus 1284
DRC- - ioPi	<b>0 / A</b> Input / <b>Rb</b> : Input ENC_A, ENC_B, ENC_I (index pulse) quadruple evaluation	0	UINT16	Profibus 1284
drE - - , oP,	<b>1 / P</b> Input / <b>Pd</b> : Input PULSE, DIR <b>2 / E</b> SIOutput / <b>ES</b> , <b>fl</b> : Output ESIM_A, ESIM_B, ESIM_I	0 2	R/W per. -	
	RS422 I/O interface (Pos)			
	IMPORTANT: Changed settings do not become active until the unit is switched on the next time.			

*Setting the resolution*

The values of the external encoder must be set using the ResolExtEncNum and ResolExtEncDenom parameters.

Example:

The motor is mounted on a linear axis with gearbox.

Gear ratio i=3:1

Linear axis: 1 revolution of the shaft corresponds to 100mm

Linear measuring system: Signal period 20 µm

Permanently set evaluation: quadruple

$$\begin{aligned} \text{ResolExtEncNum} &= 100\text{mm}(\text{travel/revolution}) * 1(\text{gear ratio}) \\ \text{ResolExtEncDenom} &= (20\mu\text{m}/4(\text{evaluation})) * 3(\text{gear ratio}) \\ \text{ResolExtEncNum} / \text{ResolExtEncDenom} &= 100/0.015 = 20000/3 \end{aligned}$$

Three motor revolutions thus create 20000 encoder increments. The value 20000 must be entered in the ResolExtEncNum parameter and the value 3 must be entered in the ResolExtEncDenom parameter.

If the calculation produces a decimal value with decimal places, the value must be rounded.

*Improved resolution is achieved if the values are multiplied.*



Example: The calculation produces 7853.98 encoder increments per revolution. Therefore, the rounded value 7854 must be entered for ResolExtEncDenom. If you do not refer to one revolution, but to 50 revolutions, for example, (ResolExtEncNum =50) a value of 392699 is produced for ResolExtEncDenom (which is thus 1 increment more accurate than the rounded value 392700).

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
ResolExtEncNum - -	Resolution of external encoder, numerator  Specification of the encoder increments the external encoder returns for one or several revolutions of the motor shaft. The value is indicated with a numerator and a denominator so that it is possible, for example, to consider the gear ratio of a mechanical gearing. In the case of opposing directions of rotations of motor encoder and external encoder, a negative numerator value must be entered. Note: The value may not be set to 0.  The resolution factor is not applied until this numerator value is specified.  Example: One motor revolution causes 1/3 encoder revolution at an encoder resolution of 16384 Enclnc/revolution.  $\frac{\text{ResolExtEncNum}}{\text{ResolExtEncDenom}} = \frac{16384 \text{ Enclnc}}{3 \text{ revolutions}}$ Available in software version V1.501 and higher.	Enclnc - 10000 -	INT32 INT32 R/W per. -	Modbus 1338 Profibus 1338
ResolExtEncDenom - -	Resolution of external encoder, denominator  Refer to ResolExtEncNum Denominator as positive 32 bit number, maximum value 1 million.  Available in software version V1.501 and higher.	revolution 1 1 1000000	INT32 INT32 R/W per. -	Modbus 1336 Profibus 1336

**Position deviation** The maximum permissible difference between the internal and the external encoder must be calculated. One motor revolution corresponds to 131072 increments. The calculated value must be entered in the p\_MaxDifToExtEnc parameter. During operation, the actual position difference can be read in the \_p\_DifToExtEnc parameter. The \_p\_DifToExtEnc parameter corresponds to the difference between p\_act and p\_act\_ExtEnc

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
p_MaxDifToExtEnc	Max. permissible deviation of encoder positions	Inc 1	INT32 INT32	Modbus 1340 Profibus 1340
-	The max. permissible position deviation between the encoder positions is cyclically monitored. If the limit is exceeded, an error is generated. The current position deviation is available via the parameter '_p_DifToExtEnc'.	65536 131072	R/W per.	-
-	The default value corresponds to 1/2 motor revolution. The maximum value corresponds to one motor revolution (should not be greater for safety reasons).			
-	Available in software version V1.501 and higher.			
_p_DifToExtEnc	Current deviation of encoder positions	Inc -	INT32 INT32	Modbus 7728 Profibus 7728
-	Available in software version V1.501 and higher.	0	R/-	-
-		-	-	-
_p_act	Actual position of motor in internal units	Inc -	INT32 INT32	Modbus 7700 Profibus 7700
-	IMPORTANT: The actual motor position is not valid until the absolute motor position has been determined. In the case of invalid absolute motor position: _WarnLatched _WarnActive Bit 13=1: Absolute motor position not yet captured	0	R/-	-
-		-	-	-
_p_actExtEnc	Actual position of external encoder in internal units	Inc -	INT32 INT32	Modbus 7730 Profibus 7730
-	Available in software version V1.501 and higher.	0	R/-	-
-		-	-	-

#### Checking direction of rotation

Before switching on check that the direction of rotation is set correctly. The actual value of the motor encoder (`_p_act` parameter) and the external encoder (`_p_act_ExtEnc` or `_p_act_ExtEncUsr`) must be read. After you have rotated the motor shaft manually (e.g. moving the carriage), both parameters must be read out again. If the counting directions are different, the sign must be changed in the `ResolExtEncNum` parameter.

An incorrect sign accelerates the motor in an uncontrolled manner (limited by `p_MaxDifToExtEnc`, position deviation).

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
_p_act	Actual position of motor in internal units	Inc - 0 -	INT32 INT32 R/- -	Modbus 7700 Profibus 7700
-	IMPORTANT: The actual motor position is not valid until the absolute motor position has been determined. In the case of invalid absolute motor position: _WarnLatched _WarnActive Bit 13=1: Absolute motor position not yet captured			
_p_actExtEnc	Actual position of external encoder in internal units	Inc - 0 -	INT32 INT32 R/- -	Modbus 7730 Profibus 7730
-	Available in software version V1.501 and higher.			
_p_actExtEncUsr	Actual position of external encoder in user units	usr - 0 -	INT32 INT32 R/- -	Modbus 7732 Profibus 7732
-	Available in software version V1.501 and higher.			
ResolExtEncNum	Resolution of external encoder, numerator	Enclnc - 10000 -	INT32 INT32 R/W per. -	Modbus 1338 Profibus 1338
-	Specification of the encoder increments the external encoder returns for one or several revolutions of the motor shaft. The value is indicated with a numerator and a denominator so that it is possible, for example, to consider the gear ratio of a mechanical gearing. In the case of opposing directions of rotations of motor encoder and external encoder, a negative numerator value must be entered. Note: The value may not be set to 0.			
-	The resolution factor is not applied until this numerator value is specified.			
-	Example: One motor revolution causes 1/3 encoder revolution at an encoder resolution of 16384 Enclnc/revolution.			
-	$\frac{\text{ResolExtEncNum}}{\text{ResolExtEncDenom}} = \frac{16384 \text{ Enclnc}}{3 \text{ revolutions}}$			
-	Available in software version V1.501 and higher.			

*Activating the external encoder*

The SelPosLoopEnc parameter acts like a switch which provides the position controller with either the position of the motor encoder or the signals from the external encoder. In order to write the parameters, the device must be in the state "Disable". The drive does not have to be restarted for the change in the parameter to become effective.

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
SelPosLoopEnc	Selection of encoder	-	UINT16	Modbus 1334
-	<b>0 / MotorEncoder:</b> Motor encoder	0	UINT16	Profibus 1334
-	<b>1 / ExtEncoder:</b> External encoder	0	R/W	
-	Available in software version V1.501 and higher.	1	per.	
			-	

*Adapting the control loop parameters for the external encoder* During initial commissioning the control loop parameters are set without activated external encoder in order to set the functionality of the entire system (Autotuning). With activated external encoder, these control loop parameters must be adapted (repeated Autotuning).

*Reference movement with external encoder* If the external encoder is active, the reference movement must be carried out with the position values of the external encoder. If the external encoder is active, a reference movement to index pulse is not possible. Since the encoder only operates incrementally, a reference movement must always be carried out.

## 2.5 Working range with multiturn encoder

*So far* When a motor with multiturn encoder is moved counter-clockwise from the absolute position 0, the multiturn encoder encounters an underrun of its absolute position. In contrast, the internal actual position counts mathematically forward and delivers a negative position value. After switching off and on, the internal actual position no longer corresponds with the negative position value but the absolute position of the encoder (e.g. a position of -10 rotations before switching off becomes an absolute position of 4086 rotations after switching on again).

*New* The `ShiftEncWorkRang` parameter is used to define whether the working range is 0...4096 rotations as it was until now or whether the working range is -2048...+2048 rotations.

*Prerequisite* • Software version from 1.501

*Function principle* `ShiftEncWorkRang = 0`: The working range is defined from 0 ... 4096 rotations. Function as described in the product manual.  
`ShiftEncWorkRang = 1`: The working range is defined from -2048 ... 2048 revolutions. With a typical application (positive and negative direction of rotation), the working range of the motor is in the constant range of the encoder.




Figure 2.2 Position values of multiturn encoder

Parameter Name HMI menu	Description	Unit Minimum value Default value Maximum value	Data type R/W persistent Expert	Parameter address via fieldbus
ShiftEncWorkRang	Shifting the encoder working range	-	UINT16	Modbus 1344
-	<b>0 / not shifted:</b> Working range: 0 to maximum number of encoder revolutions	0	UINT16	Profibus 1344
-	<b>1 / shifted:</b> Working range: negative half of maximum number of encoder revolutions to positive half of maximum number of encoder revolutions	1	R/W per.	-
	Available in software version V1.501 and higher.			



### 3 LXM05C

Functionality	Page
3.1 "Threshold values ("current threshold reached", "speed threshold reached")"	25

These new functionalities are available from software version 1.501. The leading document is the product manual for the device.

*Source product manuals*

The current product manuals are available for download from the Internet.  
<http://www.schneider-electric.com>

#### 3.1 Threshold values ("current threshold reached", "speed threshold reached")

*So far* The "current threshold reached" and "speed threshold reached" functions could only be assigned to configurable outputs in some operating modes.

*New*

- The "current threshold reached" und "speed threshold reached" functions can now be assigned to the configurable outputs in all operating modes

*Prerequisite*

- Software version from 1.501

*Function principle* The "current threshold reached" and "speed threshold reached" functions are available in all operating modes and can be assigned to the configurable outputs. (See "Configurable inputs and outputs" in the product manual).

Function	Jog	Electronic gear	Speed control	Current control
Speed threshold reached	•	•	•	•
Current threshold reached	•	•	•	•

